



MAGNI

HEADPHONE AMP AND PREAMP

IN NORSE MYTHOLOGY, MAGNI WAS ONE OF THOR'S SONS.

THIS IS OUR MAGNI. NO RELATION.


YES, WE KNOW, YOU'RE DISSAPPOINTED.

CONSOLE YOURSELF BY KNOWING YOU HAVE

THE BEST AMPLIFIER ANYWHERE NEAR ITS PRICE.

OWNER'S MANUAL

GETTING CONNECTED



1 Connect your source to the Magni's "IN" RCA jacks with high-quality RCA cables. Or you can use crappy cables (but why?)


2 Connect the supplied wall-wart cable to the jack labeled "14VAC." Do not use any other wall-wart, or bad things might happen.

3 Optional: Connect the preamp outputs to powered monitors or an external power amp.

4 Turn on the switch. The protection relay will mute the output for 15-20 seconds, then it will engage with a click.

5 Select HI or LO gain, depending on your headphones. IEMs and earbud style headphones will probably need LO gain. If you don't have enough volume control range, use LO gain.

OPERATION



1 Connect your headphones to the headphone jack, marked with a headphone icon. For smaller headphone plugs, you may need a 1/8" to 1/4" adapter (not supplied.)

2 Turn the knob to control volume to both headphone and preamp outputs. We recommend you stop increasing volume before your headphones explode.

And that's it! Enjoy your music!

Note 1: when headphones are plugged in to the Magni, the preamp outputs will mute.

Note 2: Some headphones that use TRRS plugs (typically ones with microphones, designed for use with smartphones) may have problems with some 1/8" to 1/4" headphone adapters—use a specific TRRS-TRS adapter in this case.

WHAT'S IN THE BOX

- | | | |
|--|------------------------------|---------------------------|
| (1) Magni | (0) RCA Cables | (0) Battery packs |
| (1) Wall-Wart (very nice!) | (0) Headphone adapters | (100ish) Total components |
| (0) Stick-on feet (they're pressed in now) | (0) Sexy handcrafted chassis | (1) Robotic assembly |
| | (0) Unlimited streaming | (1) Human test |



Application for Council Directives 72/23/EEC
Conformity declared for EN60065, EN50082-1

2-YEAR LIMITED WARRANTY

Schiit Audio warrants to the original purchaser that this product shall be free from defects in material and workmanship for two (2) years from the date of purchase. If a defect covered by this warranty occurs during this period, Schiit Audio will repair the defective product, free of charge. Date of purchase will be based on customer receipts, otherwise date of manufacturing will be used.

If you believe you need warranty service, contact us first. Schiit Audio products sent back to us without a Return Authorization (RA) will be returned to the sender without repair. To contact us and obtain an RA, email info@schiiit.com.

Warranty Limitations. This warranty shall not apply if a product: (a) is modified or tampered with; (b) is damaged by negligence, accident, unreasonable use, or other causes unrelated to defective materials or workmanship, or (c) has had the serial number altered or removed.

Any implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited in duration to the warranty period of 2 years. In no event shall Schiit Audio be liable for consequential or incidental damages resulting from the breach of any implied or expressed warranties. Some state do not allow these limitations, so they may not apply to you. You may also have other rights which vary from state to state or province to province.



S C H I I T

SCHIIT.COM
INFO@SCHIIT.COM